


736HPA-NV High Pressure Dispense Valve

Maintenance & Parts Guide



IMPORTANT!
Save this Sheet.

Forward to
Maintenance or
Tool Crib Supervisors

Electronic pdf files of Nordson EFD manuals are also available at nordsonefd.com



Valve Disassembly and Reassembly Procedures

To replace the lower seal:

1. Remove the three bolts from the outlet cap.
2. Remove the outlet cap.
3. Pry the seal out of the outlet cap using a small screwdriver.
4. Clean the seal cavity and then press a new seal into the cavity. Insert tapered end first, so that the O-ring faces up.
5. Inspect the fluid body O-ring and replace if necessary.
6. Reinstall the outlet cap. Tighten the three bolts to 30 to 35 inch pounds.

To replace the upper seal:


7. Remove the three bolts from the outlet cap.
8. Remove the outlet cap and fluid body.
9. Pry the seal out of the fluid body using a small screwdriver.
10. Clean the seal cavity and then press a new seal into cavity. Insert seal with O-ring facing inside the fluid body.
11. Reinstall the outlet cap and fluid body. Tighten the three bolts to 30 to 35 inch pounds.

To replace air cylinder seals:

12. Remove the three bolts from the outlet cap.
13. Remove the outlet cap and fluid body.
14. Unscrew the adjustable stroke air cap.
15. Remove the piston-and-spool assembly and the piston return spring.
16. Replace the O-rings on the spool, piston and air cylinder body.
17. Apply Nye lubricant #865 gel to piston, spool and air cylinder wall.
18. Reinstall the piston return spring, piston and spool assembly and then the adjustable stroke air cap. Tighten the air cap between 8 to 10 foot pounds.
19. Reinstall the fluid body, outlet cap and tighten the three bolts to 30 to 35 inch pounds.

CAUTION

Do not thread fluid inlet fittings too far into the valve. Doing so can obstruct the piston shaft, causing leakage, poor dispensing performance, and damage to the valve.



Accessories

1/4 NPT Metal Nozzles

Stainless steel, 38.1 mm (1.5") long. ID Size

Part #	Gauge	mm	(inches)
7014850	7	3.81	(0.150)
7014851	8	3.43	(0.135)
7014848	10	2.69	(0.106)
7014842	12	2.16	(0.085)
7014844	14	1.60	(0.063)
7014846	16	1.20	(0.047)

Polyethylene Nozzles

Plastic nozzles with 1/4 NPT thread. Nozzles may be cut or shaped as required. Supplied (10) nozzles per package.

Part #	Size
7018555	63.5 mm long x 3.2 mm opening (2 1/2" x 1/8")
7018557	63.5 mm long x 1.6 mm opening (2 1/2" x 1/16")
7018559	101.6 mm long x 1.6 mm opening (4" x 1/16")
7018561	101.6 mm long x .8 mm opening (4" x 1/32")

Maintenance Tools:

- 1/8" Allen wrench
- 5/32" Allen wrench
- (2) 8" adjustable wrenches

Dispensing Tip Adapter

Accepts all EFD dispensing tips.

Part #	Description
7021197	Adapter for use with metal tips
7021186	Adapter for use with disposable plastic tips

Valve Mounting Rod

Mounting rod dimensions are 177.8 mm long x 12.7 mm (7" x 1/2") diameter with 5/16 – 24 UNF thread.

Part #	Description
7021136	Mounting rod for the 736HPA valve

Universal Valve Mount

Use with all EFD valves for easy valve mounting.


Part #	Description
7020507	Universal valve mount

Double-Acting Air Closure Kit


The 735AC-KIT (7021143) is used in applications dispensing very thick fluids at high cycle rates. The air closure assists the spring to provide a quick, clean cut-off at the end of the dispense cycle.

Part #	Description
7021143	Air closure kit

Spool with O-ring #7021156
Includes O-ring
(Buna N) #7014743




Piston return
spring #7014740




Piston with O-ring #7021154
O-ring (Buna N) #7014738

Adjustable stroke air cylinder cap #7021127
Includes O-ring #7014735



16



Shaft lock nut
#7014742



14

Troubleshooting Guide

No fluid flow

- If valve operating pressure is too low, the valve will not open. Increase air pressure to 4.8 bar (70 psi) for timed shots and 2.7 bar (40 psi) minimum for stripes.
- The fluid pressure may not be high enough. Increase pressure.
- The dispensing tip may be clogged. Replace tip.
- Fluid may have solidified in the fluid body. Clean the fluid body.

Fluid drools after the valve closes, eventually stopping

- This is caused by air trapped in the outlet section of the fluid body or the fluid has entrapped air. The air will expand after the valve closes, causing extrusion until the air reaches atmospheric pressure. Purge the valve by dispensing at a steady flow until air is removed.
- If the fluid has entrapped air, it must be degassed before dispensing.

Fluid drips at a steady rate after the valve closes

- A steady drip indicates failure of the seal due to particle build-up or wear. Replace the seal.
- Fluid leakage can also occur when a fluid inlet fitting is threaded too far into the valve, thus obstructing the piston shaft. Ensure that the fluid inlet fitting is properly installed.

Valve responds slowly when opening and closing

- Valve response is related to control air line length and size. EFD valves are supplied with 5 feet of 4 mm (5/32") ID tubing attached. Any additional length or size change will affect response time. Check to be sure the length and size have not been changed.

Fluid flows out above upper seal

- Fluid flowing out above the upper seal indicates a worn upper seal. Replace seal.

Inconsistent deposits

- Inconsistent deposits can result if the air pressure controlling the valve and / or fluid pressure is fluctuating, or if the valve operating pressure is less than 4.8 bar (70 psi). Check air pressures and the valve operating pressure.
- The time the valve is open must be consistent. Check to be sure the valve controller is providing a consistent output.

